
SAFETY POSTER INSTRUCTIONS FOR THE SAFE HANDLING OF YOUR CUTTING TOOL

SECUMAX 148



USAGE


If the blade head gets stuck, **don't forcefully** lever the knife!

PROTECTION OF USER




The concealed blade provides maximum protection from **cut injuries**.

martor




Do not lever against staples, or force into edge protectors!



Hold the cutter at a **slight angle** when cutting open cardboard boxes.


For best results, cut plastic strapping band diagonally (at a 45° angle).




Use the **pointed nose** of the knife to pierce the film.

PROTECTION OF GOODS





The concealed blade **will not get into contact** with your goods either.



The SECUMAX 148 is a disposable knife that can be safely disposed of with your general waste.